

TAO-A.V-PHP6

TAO-A.V Option Switch Settings: 1(Pulse/ICT104V/ICT104U/MDB)

Supported bill PHP 20, 50, 100, 200, 500, 1000 6bills.

TAO-A.V dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject PHP 20	ON											
★ Accept PHP 20	OFF											
★ Reject PHP 50		ON										
★ Accept PHP 50		OFF										
★ Reject PHP 100			ON									
★ Accept PHP 100			OFF									
★ Reject PHP 200				ON								
★ Accept PHP 200				OFF								
★ Reject PHP 500 & 1000					ON							
★ Accept PHP 500 & 1000					OFF							
★ High Security					ON							
★ High Acceptance (Note.4)					OFF							
Pulse Mode	Other Mode											
★ Harness Disable	BA stops working when fishing				ON							
★ Harness Enable	Normal				OFF							
★ Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ 1 pulse / PHP 10								OFF	OFF			
★ 5 pulses / PHP 10								ON	OFF			
★ 10 pulses / PHP 10								OFF	ON			
★ 20 pulses / PHP 10								ON	ON			
★ Interface Timing Conversion	50ms LO / 50ms HI									OFF	OFF	
	60ms LO / 300ms HI									ON	OFF	
	30ms LO / 50ms HI									OFF	ON	
	150ms LO / 150ms HI									ON	ON	

★ Manufacture setting

◆ Note.1: Default setting

Note.2: Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

Note.3: Remove the front cover and the dip-switch in on the CPU board.

(Please refer to "SW1" setting.)

Note.4: High acceptance mode will increasing accepting rate, however, it will reduce the security level of Bill Acceptor.

TAO-A.V-PHP6(Pulse/ICT104V/ICT104U/MDB)

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON	OFF	
ICT104V Interface		OFF	ON	
ICT104U Interface		OFF	OFF	
MDB Interface		ON	ON	
★ Reserved				ON
				OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	ICT	Pulse	MDB
BV1	PHP 20	PHP 20	PHP 20
BV2	PHP 50	PHP 50	PHP 50
BV3	PHP 100	PHP 100	PHP 100
BV4	PHP 500	PHP 200	PHP 200
BV5	PHP 1000	PHP 500	PHP 500
BV6	PHP 200	PHP 1000	PHP 1000

Interface Settings: 2(ICT104V)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON	OFF	
★ ICT104V Interface		OFF	ON	
ICT104U Interface		OFF	OFF	
MDB Interface		ON	ON	
★ Reserved				ON
				OFF

★ Manufacture setting

Interface Settings: 2(ICT104U)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON	OFF	
★ ICT104V Interface		OFF	ON	
ICT104U Interface		OFF	OFF	
MDB Interface		ON	ON	
★ Reserved				ON
				OFF

★ Manufacture setting

TAO-V-PHP6

Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100	ON			
Decimal Point Position (DPP) = 2				
Scaling Factor (SF) = 1	OFF			
Decimal Point Position (DPP) = 0				
Pulse Mode		ON	OFF	
ICT104V Interface		OFF	ON	
ICT104U Interface		OFF	OFF	
★ MDB Interface		ON	ON	
★ Reserved				ON
				OFF

★ Manufacture setting